

1

After logging into myLDR.Landauer.com, click "Dosimeters" on the main menu. Then click "Participant dosimeters".

LANDAUER®

Participants

Dosimeters

Reports

RadFacts™

Accounts

Shipment tracking

Participants

Dose historyAssigned dose

MonthQuarterYear<Year 2024>

☒ Active☐ Inactive

Filters:

Accounts

+ Add filter

Name ↑	Account
AAAANDERS, ANDERS	

LANDAUER®

Participants

Dosimeters

Area monitors

Participant dosimeters

Spare dosimeters

Unreturned dosimeters

Reports

RadFacts™

Participants

Dose historyAssigned dose

MonthQuarterYear<Year 2024>

☒ Active☐ Inactive

Filters:

Accounts

+ Add filter

Name ↑	Account
<input type="checkbox"/> AAAANDERS, ANDERS 03532	182051 CLIENT EXPERIENCE
<input type="checkbox"/> ADDPART, FEB28 01844	182051 CLIENT EXPERIENCE

2 View the status of the dosimeter in the "Status" column.

Custom

First name or last name

▼

DosimeterStatus
All

Export

Manage columns

Serial Number	DDE mrem	LDE mrem	SDE mrem	EXT mrem	Status	Dosimeter Location	Used
6792164B	--	--	--	--	Active Monitoring	Chest	Used
3575315B	--	--	--	--	Awaiting Receipt	Fetal	Used
4175210B	--	--	--	--	Awaiting Receipt	Chest	Used
5344105B	--	--	--	--	Awaiting Receipt	Fetal	Used
3927868A	--	--	--	--	Awaiting Receipt	Fetal	Used
5344079B	--	--	--	--	Awaiting Receipt	Chest	Used

Rows per page: 100
1-6 of 6



Tip! You can use the filters at the top of the "participant dosimeters" screen to narrow your search results if you wish. The status for any given dosimeter will be one of the 4 following options: **1) Active monitoring** - the dosimeter is still in use/the wear period has not ended yet. **2) Awaiting Receipt** - the wear period has ended and Landauer is waiting to receive the dosimeter from your facility. **3) Processing Dose** - the dosimeter has been received and is now being processed/read for dose results. **4) Reported** - the dosimeter has been processed and the report is now available to view/download.